

VESDA VLQ

Product Guide

VLQ-100

February 2014

Document: 26104_03

Part Number: 30320



Singapore +65 6757 7045

Indonesia +62 21 8778 2069



Intellectual Property and Copyright

This document includes registered and unregistered trademarks. All trademarks displayed are the trademarks of their respective owners. Your use of this document does not constitute or create a licence or any other right to use the name and/or trademark and/or label.

This document is subject to copyright owned by Xtralis AG ("Xtralis"). You agree not to copy, communicate to the public, adapt, distribute, transfer, sell, modify or publish any contents of this document without the express prior written consent of Xtralis.

Disclaimer

The contents of this document is provided on an "as is" basis. No representation or warranty (either express or implied) is made as to the completeness, accuracy or reliability of the contents of this document. The manufacturer reserves the right to change designs or specifications without obligation and without further notice. Except as otherwise provided, all warranties, express or implied, including without limitation any implied warranties of merchantability and fitness for a particular purpose are expressly excluded.

General Warning

This product must only be installed, configured and used strictly in accordance with the General Terms and Conditions, User Manual and product documents available from Xtralis. All proper health and safety precautions must be taken during the installation, commissioning and maintenance of the product. The system should not be connected to a power source until all the components have been installed. Proper safety precautions must be taken during tests and maintenance of the products when these are still connected to the power source. Failure to do so or tampering with the electronics inside the products can result in an electric shock causing injury or death and may cause equipment damage. Xtralis is not responsible and cannot be held accountable for any liability that may arise due to improper use of the equipment and/or failure to take proper precautions. Only persons trained through an Xtralis accredited training course can install, test and maintain the system.

Liability

You agree to install, configure and use the products strictly in accordance with the User Manual and product documents available from Xtralis.

Xtralis is not liable to you or any other person for incidental, indirect, or consequential loss, expense or damages of any kind including without limitation, loss of business, loss of profits or loss of data arising out of your use of the products. Without limiting this general disclaimer the following specific warnings and disclaimers also apply:

Fitness for Purpose

You agree that you have been provided with a reasonable opportunity to appraise the products and have made your own independent assessment of the fitness or suitability of the products for your purpose. You acknowledge that you have not relied on any oral or written information, representation or advice given by or on behalf of Xtralis or its representatives.

Total Liability

To the fullest extent permitted by law that any limitation or exclusion cannot apply, the total liability of Xtralis in relation to the products is limited to:

1. in the case of services, the cost of having the services supplied again; or
2. in the case of goods, the lowest cost of replacing the goods, acquiring equivalent goods or having the goods repaired.

Indemnification

You agree to fully indemnify and hold Xtralis harmless for any claim, cost, demand or damage (including legal costs on a full indemnity basis) incurred or which may be incurred arising from your use of the products.

Miscellaneous

If any provision outlined above is found to be invalid or unenforceable by a court of law, such invalidity or unenforceability will not affect the remainder which will continue in full force and effect. All rights not expressly granted are reserved.

Scope

The VESDA VLQ Product Guide provides a comprehensive description of the VLQ detector.

This guide introduces the VESDA VLQ features, technical specifications and gives an understanding of its components and their function. You will also find instructions on installing, cabling and powering up the detector.




This guide is for anyone involved with the design, maintenance and purchasing of a VESDA VLQ system. It is assumed that anyone using this product has the knowledge and appropriate certification from local fire and electrical authorities.

Document Conventions

The following typographic conventions are used in this document:

Convention	Description
Bold	Used to denote: emphasis. Used for names of menus, menu options, toolbar buttons
<i>Italics</i>	Used to denote: references to other parts of this document or other documents. Used for the result of an action.

The following icons are used in this document:

Convention	Description
	Caution: This icon is used to indicate that there is a danger to equipment. The danger could be loss of data, physical damage, or permanent corruption of configuration details.
	Warning: This icon is used to indicate that there is a danger of electric shock. This may lead to death or permanent injury.
	Warning: This icon is used to indicate that there is a danger of inhaling dangerous substances. This may lead to death or permanent injury.

Contact Us

UK and Europe	+44 1442 242 330
D-A-CH	+49 431 23284 1
The Americas	+1 781 740 2223
Middle East	+962 6 588 5622
Asia	+86 21 5240 0077
Australia and New Zealand	+61 3 9936 7000
www.xtralis.com	

Codes and Standards Information for Air Sampling Smoke Detection

We strongly recommend that this document is read in conjunction with the appropriate local codes and standards for smoke detection and electrical connections. This document contains generic product information and some sections may not comply with all local codes and standards. In these cases, the local codes and standards must take precedence. The information below was correct at time of printing but may now be out of date, check with your local codes, standards and listings for the current restrictions.

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, the user is encouraged to try to correct the interference by one or more of the following measures; re-orientate or relocate the receiving antenna, increase the separation between the equipment and receiver, connect the equipment to a power outlet which is on a different power circuit to the receiver or consult the dealer or an experienced radio/television technician for help.

FDA

This Xtralis product incorporates a laser device and is classified as a Class 1 laser product that complies with FDA regulations 21 CFR 1040.10. The laser is housed in a sealed detector chamber and contains no serviceable parts. The laser emits invisible light and can be hazardous if viewed with the naked eye. Under no circumstances should the detector chamber be opened.

The laser chamber is identified by the label shown below:



Product Listings

- UL
- ULC
- VNIPPO
- EN 54-20 and other agencies (pending)

Document: 26104_03

Part Number: 30320

This page is intentionally left blank.

Table of Contents

1	Introduction	3
1.1	Features	4
2	Product Information	5
2.1	How it Works	5
2.2	Detector Overview	6
2.3	Specifications	9
2.4	Dimensions	10
3	Air Sampling Pipe Network	11
3.1	Installation Considerations	11
3.2	Pipe Inlets	11
3.3	Exhaust Air	11
3.4	Air Sampling Configurations	12
4	Installation	15
4.1	Mounting	16
4.2	Wiring	22
4.3	Specify Backup Battery for Power Supply	25
4.4	Installation Checklist	26
4.5	Powering Up	27
4.6	Preliminary System Check	27
5	Configuration	29
5.1	Logging on using the Display Panel	29
5.2	Setting the time using the Display Panel	29
5.3	DIP Switch Configuration	30
6	Commissioning	31
6.1	AutoLearn Smoke	31
6.2	Commissioning Smoke Test	31
7	Xtralis QSC Software	33
7.1	Installation	33
7.2	Functions	33
7.3	Configuration	34
7.4	Device Information	35
8	Maintenance	37
8.1	Replacing the Filter	37
9	Troubleshooting	41
9.1	Fault Codes	41

This page is intentionally left blank.

1 Introduction

The VESDA VLQ is an Aspirating Smoke Detector (ASD) that provides very early warning of fire conditions by drawing air samples through sampling holes located in an air sampling pipe network.

The VESDA VLQ detector is specifically designed to cater for small areas up to 100 m² (1000 ft²). VESDA VLQ is suited to several applications, including but not limited to:

- Telecommunications land line remote offices
- Base station controllers (BSC)
- Base transceiver stations (BTS)
- Server rooms
- Datacenter containers
- IT/equipment cabinets
- Controlled environmental vaults (CEV)
- Semi-conductor tools
- Modular laboratories
- Anechoic chambers
- Flight simulators
- Generator enclosures
- Signaling huts
- Pump houses
- Ammunitions holding areas
- Hyperbaric chambers
- Barracks self-contained units

Connection to the detector using Xtralis QSC software is available via the USB interface.



Figure 1-1: VESDA VLQ

The detector contains dry-contact relays which allow connectivity to fire warning and fire suppression release systems, and integration into a building management system (BMS).

1.1 Features

The VESDA VLQ detector provides the following features:

- Laser-based absolute smoke detection
- Clean air barriers for optics protection
- Up to 100 m² (1000 ft²) coverage
- Up to 2 x 6m (2 x 20ft) pipes (straight), up to 2 x 9m (2 x 30ft) pipes (branched)
- 2 or 4 VEWFD / EWFD (NFPA76), or 2 or 4 Class A / Class B (EN 54-20) sample holes
- Metric/Imperial pipe inlets
- Pre-alarm, Alarm and Fault Relays
- 5 LEDs: Pre-alarm, Fire-alarm, Fault, Power, Filter replacement
- Monitored on-board filter
- AutoLearn Smoke
- General Purpose Input (GPI)
- IP30 enclosure
- Xtralis QSC software support
- USB for direct PC connection
- Event log
- Low power consumption

2 Product Information

2.1 How it Works

The VESDA VLQ detector continually samples air from the protected environment via two pipe inlets for the sampling pipes on each side of the pipe inlets (A1, A2). Upon entering the detector, the air passes through respective inlet manifolds (B1, B2) and the aspirators (C1, C2). The sampled air then enters the filter (D) where the majority is exhausted out through filter exhaust (I2) and a portion from each inlet is separated into two pathways, one pathway enters as clean air (E1,E2) and the other pathway enters as sampled air (F1,F2) into the detection chamber (G). Sampled air is used for smoke detection and the clean air used for optics protection. After smoke detection the air is exhausted out of the chamber exhaust (I1). Flow measurement is performed at the chamber exhaust (H).




Figure 2-1: Air Path

2.2 Detector Overview

The VESDA VLQ detector is a lightweight unit designed to be ceiling or wall mounted and operates with a simple sampling pipe network. The detector unit features two sampling pipe inlets, unobtrusive exhaust vents, a simple control panel and display, and a buzzer to provide audio notifications.

A USB port, described below in Section 2.2.3, provides the ability to interface with a computer, which allows configuration with the Xtralis QSC software. Configuration DIP switches and wiring terminals are located beneath the detector and are accessible by removing the detector base..




Figure 2-2: VESDA VLQ Detector Overview

2.2.1 Front Panel

The VESDA VLQ front panel contains a series of indicators and buttons. These are described below.




Figure 2-3: VESDA VLQ Front Panel and Status LEDs

Indicators

The VESDA VLQ detector provides information via a series of Status LEDs.

Table 2-1: LED Indicators

LED	Color	Description
A Power	Green	The Power LED illuminates when the detector is powered up.
B Filter Replacement	Yellow	The Filter Replacement LED is lit when the filter is due for replacement.
C Fault	Yellow	The Fault LED is lit when a fault condition is detected.
D Pre-Alarm	Red	The Pre-Alarm LED is lit when the Pre-Alarm threshold is reached.
E Fire-Alarm	Red	The Fire LED is lit when the Fire threshold is reached.

Buttons

The VESDA VLQ detector provides accessibility to a range of functions via a set of control buttons.

Table 2-2: Control Buttons





Button		Description
Reset / Silence		<p>Resetting the detector unlatches all latched alarms and faults, returns relays to their normal state and clears the active event list.</p> <p>Silencing silences the buzzer for the current fault.</p> <ul style="list-style-type: none"> To reset the detector, press this button once, 'rs' is displayed on the panel. To silence the buzzer, press and hold this button till "SI" is displayed on the panel (5 to 10 seconds). SI is displayed alternately with the highest priority fault code. The buzzer will remain silent unless another fault is reported. To take detector out of Silence mode, press this button once while detector is displaying "SI". <p>While the filter is removed, pressing the Reset / Silence button once will reset the filter use percentage value.</p>
Disable / Standby		<p>Disabling the detector disables all relay outputs with the exception of the fault relay. The aspirator remains active.</p> <p>Standby shuts down the aspirator and puts the detector standby mode. There is no smoke detection during standby, and the fault relay is activated.</p> <ul style="list-style-type: none"> To disable the detector, press this button once. To re-enable the unit, press the button while "db" is displayed on the panel. To place the detector in standby mode, press and hold this button until "Sb" is displayed on the panel (5 to 10 seconds). To take detector out of standby mode, push and hold this button when "Sb" is displayed on the panel (5 to 10 seconds). <p>Note: You must be logged on to the detector through front panel to use this button. Refer to Section 5.1 for further information.</p>
Test		<p>Two Test modes are available:</p> <ul style="list-style-type: none"> Lamp and Buzzer Test: Press this button to ensure that all LEDs, display segments and buzzer operate correctly. "Lt" is displayed momentarily when the button is pressed. Alarm and Fault Test: Press and hold this button until "At" is displayed on the front panel (5 to 10 seconds). It activates alarm and fault relays. To stop the test press and hold this button when "At" is displayed on the panel. <p>Note: You must be logged on to the detector through front panel to use this button. Refer to Section 5.1 for further information.</p>

Table 2-2: Control Buttons (continued...)

Button		Description
Normalize Airflow / AutoLearn Smoke		<p>Airflow Normalization sets the reference point for airflow thresholds based on ambient operating conditions.</p> <p>AutoLearn Smoke sets the alarm thresholds based on the environmental conditions.</p> <ul style="list-style-type: none"> • Press this button once to start the flow normalization, 'no' is displayed on the panel. Normalization takes between 5 to 10 minutes. To cancel normalization press this button while 'no' is displayed. • To start the AutoLearn smoke press and hold this button till "AL" is displayed on the panel. AutoLearn takes 15 minutes to complete when started from the panel. To cancel the AutoLearn press and hold this button when "AL" is displayed. <p>Notes:</p> <ul style="list-style-type: none"> • AutoLearn Smoke thresholds are volatile, therefore if thresholds are set using AutoLearn smoke then it must be run each time the detector is powered up. • AutoLearn Smoke over-rides the DIP switch settings within the smoke threshold range. Refer to Section 5.3 for further information. • You must be logged on to the detector through the front panel to use this button. Refer to Section 5.1 for further information.

2.2.2 Buzzer

The buzzer will sound under the following conditions:

- During power up self testing.
- When a Pre-Alarm is raised, the buzzer will alternate between on and off until the detector is silenced or the smoke is no longer present.
- When a Fire alarm is raised, the buzzer will beep continuously until the detector is silenced or the smoke is no longer present.
- When a Fault is detected, the buzzer will alternate between on and off until the detector is silenced or the fault condition is corrected.
- During a manually initiated system test.

2.2.3 USB Port

Detector configuration can be performed using the Xtralis QSC software installed on a computer connected to the detector via the USB port. The USB port is located on the outside of the detector, beneath the shroud. It is necessary to remove the rubber grommet in order to access this port.




Figure 2-4: USB Port

2.3 Specifications

Table 2-3: VLQ Detector Specifications

Specification	Value
Supply Voltage	24 VDC nominal (18 to 30 VDC), externally supplied from UL1481 / EN54-4 listed power supply (as appropriate to meet local codes). Ensure that the power supply is installed in accordance with local electrical codes.
Current Consumption	170 mA (quiescent), 190 mA (alarm)
Dimensions	260 mm x 228 mm x 110 mm (10.24in x 8.98in x 4.35in)
Weight	1.2 Kg (2.65 lbs)
Operating Conditions (To operate the VESDA VLQ detector outside these parameters please contact your nearest Xtralis Office.)	<p>Temperature:</p> <ul style="list-style-type: none"> • Tested to: -10°C to 55°C (14°F to 131°F) * • Recommended Ambient: 0°C to 39°C (32°F to 103°F) <p>Humidity:</p> <ul style="list-style-type: none"> • 0-95% RH, non-condensing
Sampling Pipe Network	<p>Pipe Length:</p> <ul style="list-style-type: none"> • Linear: Up to 2 x 6 m (2 x 20 ft.) • Branched: Up to 2 x 9 m (2 x 30 ft.) <p>Sampling Holes:</p> <ul style="list-style-type: none"> • 2 or 4 (1 or 2 per pipe) <p>Refer to Section 3.4 on page 12 for further information.</p>
Pipe Size	Accepts both metric and American standard pipe sizes: <ul style="list-style-type: none"> • Metric: 25 mm (1.05 in.) • American Pipe: IPS 21 mm (¾ in.)
Relays	<ul style="list-style-type: none"> • 3 relays. Pre-Alarm, Fire and Fault • Contacts rated 2A @ 30 VDC • Programmable to latch or non-latch states • Programmable 0 - 60 sec delay for each relay
IP Rating	IP30
Mounting	Surface or flush mounting with optional mounting brackets.
Cable Access	<ul style="list-style-type: none"> • Two cabling inlet points from top • Side entry through removable partition
Cable Termination	Screw terminal blocks (0.2-2.5 sq mm, 30-12 AWG)
PC Connection	USB (Type 2)
Sensitivity Range	0.005% - 3% obs/m (0.0015% - 0.915% obs/ft)
Threshold Setting Range	<ul style="list-style-type: none"> • Fire Alarm: 0.15%/m - 3%/m (0.046%/ft - 0.915%/ft) • Pre-Alarm: 0.1%/m - 1.5%/m (0.03%/ft - 0.457%/ft)

* Product UL listed between 0° to 39°C (32° F to 103° F)

Table 2-4: Software Features

Specification	Value
Event Log	Up to 1,000 events

Table 2-4: Software Features (continued...)

Specification	Value
AutoLearn Smoke	<ul style="list-style-type: none"> • Minimum: 15 minutes • Maximum: 2 Hours (through Xtralis QSC) • Recommended minimum period: 1 hour <p>Thresholds are automatically changed from the previously set values to the updated values after the AutoLearn process has completed. AutoLearn Smoke over-rides the DIP switch settings within the smoke threshold range.</p>
Maintenance Aids	<ul style="list-style-type: none"> • Event log • Smoke log

2.3.1 Ordering Information

Table 2-5: Ordering Information

Part Number	Description
VLQ-100	Detector
VSP-890	Surface Mount Kit
VSP-891	Flush Mount Kit
VSP-892	Replacement Filter
VSP-892-20	Replacement Filter - 20 pieces
VSP-893	Pipe Kit (Metric)
VSP-893-US	Pipe Kit (Imperial)

2.4 Dimensions




Figure 2-5: Detector Dimensions

3 Air Sampling Pipe Network

The detector uses two linear pipes of up to 6 m (20 ft) or two branched pipes of up to 9 m (30ft) to cover a maximum of 100 m² (1000 ft²). Short pipes can be used to suit the installation.

3.1 Installation Considerations

The following points should be considered when installing sampling pipe:

- Minimize flexing in sampling pipes by supporting the pipe every 1.5 m (5 ft) or less, or at a distance described in local codes and standards.
- Sampling pipe fits firmly into the tapered detector port, DO NOT glue this connection.
- Allow sufficient movement at the detector to permit pipe removal for maintenance.
- Pipe ends must be made smooth for bonding.
- Sampling holes must be drilled in line and perpendicular to the pipe.
- Sample holes must be clear of rough edges and debris.
- Ensure that all sampling holes are from within a single space (not physically different areas separated by walls).
- Ensure that there is no pressure differential between sampling holes and exhaust ports.
- Pipes are free of debris.
- All joints must be glued except the pipes entering the detector.

Notes:

- Sampling holes should face into the direction of airflow, or point downwards in static airflow situations. For return air sampling refer to the notes in Section 3.4 on page 12.
- For code-specific information, see Codes and Standards Information for Air Sampling Smoke Detection on page iii.

3.2 Pipe Inlets

The VESDA VLQ detector supports two sampling pipes. Both pipes must be connected for proper detector operation.

The air inlet ports are tapered such that they accommodate both 25 mm (1 in) or IPS ¾ inch (1.05 in outer diameter) pipes. Each air inlet port allows maximum insertion of the sampling pipe to a depth of 15 mm (0.60 in).

While connecting the detector to the pipe network:

- Square off and de-burr the end of the sampling air pipes, ensuring the pipes are free from debris.
- Insert the pipes into the pipe inlet(s) ensuring a firm fit.

Note: DO NOT glue the pipes to the pipe inlets.

3.3 Exhaust Air

Air is expelled from the detector via the filter and after the detection chamber into the area where the detector is located. Refer to Figure 2-2 on page 6.

There should be no pressure differential between the sampling holes and the exhaust ports.

3.4 Air Sampling Configurations

Both inlets must be fitted with pipes with 1 or 2 holes and the configuration must comply to the rules in Table 3-1 below.





Table 3-1: Pipe and Sampling Hole Rules

Description	1 hole per pipe	2 holes per pipe	Combined Inlet
Minimum pipe length per inlet	15 cm (6 in)	15 cm (6 in)	n/a
Maximum linear pipe length per inlet / combined inlet from detector to furthest sampling hole	6 m (20 ft)	6 m (20 ft)	6 m (20 ft)
Maximum branched pipe length per inlet (total)	n/a	9 m (30 ft)	n/a
Maximum distance in branched pipe from detector to furthest sampling hole	n/a	6 m (20 ft)	n/a
Furthest sampling hole distance from the detector	6 m (20 ft)	6 m (20 ft)	6 m (20 ft)
Hole sizes per pipe / combined inlet pipe	1 x 6.5 mm (1/4")	2 x 4.5 mm (11/64")	2 x 6.5 mm (1/4") or 4 x 4.5 mm (11/64")
Maximum capillary length	30 cm (1 ft)	30 cm (1 ft)	30 cm (1 ft)

Notes:

- Ensure that all sampling holes are from within a single space (not physically separated by walls).
- Ensure that there is no pressure differential between sampling holes and the exhaust port.
- Ensure that the number of bends does not exceed four (4) per inlet and per branch.
- Do not use a single VLQ to perform ceiling and return air grille detection.
- For return air grille detection, the pipe can be routed to the return air grille whilst the detector is installed away from the return air grille. The sampling holes must be oriented 30° to the incoming airflow direction.
- Ensure that the air sampling configuration complies to local codes and standards.
- Ensure that the rules in Table 3-1 are followed when a single hole per inlet or two holes per inlet are used.
- When the air sampling pipes are unbalanced, for example configurations 2A, 3B, 4C shown in Table 3-2 below, smoke entering the holes closer to the detector will trigger an alarm earlier than smoke entering the furthest holes.

Table 3-2: Air Sampling Configurations

No. of Sampling Locations	Example Detector Configurations	Description	Fire-Alarm Threshold Setting Upper Limit - %/m (%/ft)		
			NFPA76 VEWFD / EN 54-20 Class-A	NFPA76 EWFD / EN 54-20 Class-B	NFPA76 SFD / EN 54-20 Class-C
1		<p>These are the recommended configurations for small protected areas where a single sampling location is required.</p> <ul style="list-style-type: none"> • A: 2 x 4.5mm (11/64") holes per inlet or 1 x 6.5mm (1/4") hole per inlet. • B: 4 x 4.5mm (11/64") or 2 x 6.5mm (1/4") holes close to each other for a combined inlet configuration. 	0.4 (0.125)	0.8 (0.25)	3 (0.937)
2		<p>These are the recommended configurations for small protected areas where two sampling locations are required.</p> <ul style="list-style-type: none"> • A, B: 2 x 4.5mm (11/64") holes per inlet or 1 x 6.5mm (1/4") hole per inlet. • C: 2 x 6.5mm (1/4") holes 	0.2 (0.063)	0.4 (0.125)	3 (0.937)
3		<p>These are the recommended configurations for protected areas where three sampling locations are required.</p> <ul style="list-style-type: none"> • 2 x 4.5mm (in) holes per inlet. 	0.15 (0.046)	0.3 (0.094)	2 (0.625)
4		<p>These are the recommended configurations to maximize the area coverage with four sampling locations.</p> <ul style="list-style-type: none"> • 2 x 4.5mm (in) holes per inlet. 	0.15 (0.046)	0.3 (0.094)	2 (0.625)

This page is intentionally left blank.

4 Installation

The VESDA VLQ detector is shipped with the following components:

- VESDA VLQ detector, including base
- Flush Mount or Surface Mount bracket kits (ordered separately)
- Stub pipes and end caps (ordered separately)

Check all components for damage and refer any concerns to your authorized representative.

It may be necessary to procure the following items:

- Generic third party wiring junction box
- Type A to Mini Type B USB Interface Lead for configuration purposes.



Figure 4-1: Type A to Mini Type B USB Interface Lead

4.1 Mounting

Depending on the type of surface, the VESDA VLQ detector can be installed in different ways to suit environmental, aesthetic and local code requirements. There are several mounting techniques described in this section to suit different mounting surfaces

The detector base is used in all mounting techniques in conjunction with either the surface mount bracket or flush mount bracket to secure the detector to the mounting surface.




Figure 4-2: Detector base and mounting brackets

When the detector is attached to the detector base, the sampling pipes on the detector must be aligned with the sampling pipe markers on the base. Push the detector into the base on 45 degree counter-clockwise rotation, then rotate 45 degrees clockwise to lock into place.




Figure 4-3: Fit detector to base and rotate clockwise

4.1.1 Surface Mount on Hard Ceiling / Wall

4.1.1.1 Mounting with Junction Box

This mounting technique is used where conduit and cable entry is required on the surface of the wall or ceiling.




Figure 4-4: Ceiling mounted with Junction Box

1. Secure the Junction Box (A) to the hard surface with appropriate fasteners.
2. Connect wiring conduit (C) to Junction Box and pass the wires through.
3. Remove the detector base from the detector body by holding the detector body and rotating the base anti-clockwise.
4. Pass wires through the detector base and screw the detector base to the Surface Mount Bracket (B).
5. Screw the surface mount bracket to the junction box and pass the wires through its holes, ensuring that the sampling pipe inlet arrows on the surface mount bracket are appropriately positioned.
6. Feed wires through the wire retaining strip on the base of the detector and attach to the appropriate terminal block connectors.
7. Fit the terminal block connectors to the appropriate sockets on the terminal block.
8. Align detector body to the base so that there is room to rotate it clockwise, ensuring that pipe inlets match the arrows shown on the detector body.
9. Insert pipes into the pipe inlets and seat them tightly.

4.1.1.2 Mounting without Junction Box

This mounting technique is used where concealed cable entry is possible.





Figure 4-5: Ceiling mounted with no Junction Box

1. Remove the detector base from detector body by holding the detector body and rotating the base anti-clockwise.
2. Secure the detector base to the hard surface with appropriate fasteners, ensuring that the sampling pipe inlet arrows on the detector base are appropriately positioned.
3. Remove the appropriate number of side teeth above the sloped front panel cover (Figure 4-6) to allow wires to pass through.
4. Feed wires through the wire retaining strip on the base of the detector and attach to the appropriate terminal block connectors.
5. Fit the terminal block connectors to the appropriate sockets on the terminal block.
6. Align detector body to the base so that there is room to rotate it clockwise, ensuring that pipe inlets match the arrows shown on the detector body.
7. Insert pipes into the pipe inlets and seat them tightly.



Legend	
A	Remove Teeth

Figure 4-6: Remove teeth to provide cabling access

4.1.2 Surface Mount on Suspended Ceiling Tile

4.1.2.1 Mounting with Junction Box

The Surface Mount Bracket is used behind the ceiling tile to spread the detector fixing load across a weak surface.




Figure 4-7: Mount on suspended Ceiling Tile with Junction Box

1. Remove the ceiling tile on which installation is required.
2. Remove the detector base from the detector body by holding the detector body and rotating the base anti-clockwise
3. Use the Surface Mount Bracket (B) to mark and then cut holes for connection with the detector base (3 screws) and the holes for the wiring inlets ensuring that the sampling pipe inlet arrows on the surface mount bracket are appropriately positioned.
4. Connect wiring conduit to the Junction Box (A) and screw the Surface Mount Bracket into the Junction Box.
5. Insert Junction Box and surface mount bracket assembly from top side of the ceiling tile and screw the detector base to the surface mount bracket from the bottom side of the ceiling tile, ensuring that the sampling pipe inlet arrows on the detector body are appropriately positioned.
6. Put the ceiling tile back in its position and pass the wires through the wiring conduit, junction box, surface mount bracket holes and detector base holes.
7. Secure the Junction Box (A), wiring conduit and Surface Mount Bracket (B) in the ceiling void in accordance with local electrical codes.
8. Feed wires through the wire retaining strip on the base of the detector and attach to the appropriate terminal block connectors.
9. Fit the terminal block connectors to the appropriate sockets on the terminal block.
10. Align detector body to the base so that there is room to rotate it clockwise and then slide it into the detector body, ensuring that pipe inlets match the arrows shown on the detector body.
11. Insert pipes into the pipe inlets and seal them tightly.

4.1.2.2 Mounting without Junction Box

The Surface Mount Bracket is used behind the ceiling tile to spread the detector fixing load across a weak surface.




Figure 4-8: Mount on suspended Ceiling Tile with no Junction Box


1. Remove the ceiling tile on which installation is required.
2. Remove the detector base from the detector body by holding the detector body and rotating the base anti-clockwise.
3. Use Surface Mount Bracket (A) to drill three mounting holes and two wiring holes into the ceiling tile, ensuring that the sampling pipe inlet arrows on the surface mount bracket are appropriately positioned.
4. Insert Surface Mount Bracket from top side of the ceiling tile and screw the detector base into it from the bottom side of the ceiling tile.
5. Put the ceiling tile back in its position and pass the wires through the surface mount bracket and detector base holes.
6. Secure the surface mount bracket in the ceiling void in accordance with local electrical codes.
7. Feed wires through the wire retaining strip on the base of the detector and attach to the appropriate terminal block connectors.
8. Fit the terminal block connectors to the appropriate sockets on the terminal block.
9. Align detector body to the base so that there is room to rotate it clockwise, ensuring that pipe inlets match the arrows shown on the detector body.
10. Insert pipes into the pipe inlets and seal them tightly.

4.1.3 Flush Mount on Suspended Ceiling Tile

Flush mounting places the sampling pipes inside the ceiling cavity and the detector body in the protected area.

Note: There must be no significant pressure differential between the ceiling cavity and the protected area.

4.1.3.1 Mounting with Junction Box



Legend	
A	Ceiling Tile
B	Flush Mount Bracket
C	Generic third party Junction Box
D	Surface Mount Bracket

Figure 4-9: Flush Mount on suspended Ceiling Tile with Junction Box

1. Remove the ceiling tile (A) on which installation is required.
2. Use the Flush Mount Bracket (B) to cut the tile to pass the detector body and drill four holes for the shroud screws.
3. Remove the Shroud (E), pipe inlet fascia (F) and snap-offs (G) from both pipe inlets (Figure 4-10).





Figure 4-10: Remove shroud, pipe inlet fascia and snapoffs

4. Place the Flush Mount Bracket (B) from the top side of the tile and screw the Shroud (E), placed from the bottom side of the ceiling tile.
5. Remove the detector base from the detector body by holding the detector body and rotating the base anti clockwise.
6. Screw the Junction Box (C) to the Surface Mount Bracket (D) with appropriate fasteners.
7. Screw the Junction Box with Surface Mount Bracket to the Detector Base, then pass the wires from the conduit through to the Junction Box (C), Surface Mount Bracket (D) and Detector Base. (Do not connect conduit to the Junction Box yet.)
8. Feed wires through the wire retaining strip on the base of the detector and attach to the appropriate terminal block connectors.
9. Fit the terminal block connectors to the appropriate sockets on the terminal block.
10. Align detector base to the detector body so that there is room to rotate it anti-clockwise and then slide the detector body into the detector base, ensuring that pipe inlets match the arrows shown on the detector body.
11. Insert the detector body from the top side of the tile and snap fit to the Shroud (E).
12. Where applicable, reposition the ceiling tile (A).
13. Connect wiring conduit to the Junction Box (C).
14. Secure the Flush Mount Bracket (B) in the ceiling void in accordance with local electrical codes.
15. Insert pipes into the pipe inlets and seal them tightly. Use short capillary tubes (maximum 30 cm / 1 ft) with appropriate sampling heads.

4.1.3.2 Mounting without Junction Box



Legend	
A	Ceiling or Ceiling Tile
B	Flush Mount Bracket
C	Detector Base Holes

Figure 4-11: Flush Mount on suspended Ceiling Tile with no Junction Box

1. Follow steps 1 to 5 from the previous section.
2. Pass the wires through the detector base holes (C).
3. Feed wires through the wire retaining strip on the base of the detector and attach to the appropriate terminal block connectors.
4. Fit the terminal block connectors to the appropriate sockets on the terminal block.
5. Align detector base body to the detector body so that there is room to rotate it anti-clockwise, ensuring that pipe inlets match the arrows shown on the detector body.
6. Support the flush mount bracket in the ceiling void in accordance with local electrical codes.
7. Insert pipes into the pipe inlets and seat them tightly. Use short capillary tubes (maximum 30cm/1ft) with appropriate sampling heads.

4.2 Wiring

The terminal block connectors located on the underside of the VESDA VLQ detector will accept 0.2 - 2.5 mm² or 30-12 AWG wire sizes.

4.2.1 Cabling Inlet

There are two cabling inlet ports. The ports are fitted with rubber grommets. They are not intended for wiring conduit connections. System designs that use conduit must use the optional brackets and junction box.

4.2.2 Wiring Terminals

The wiring terminals are located beneath the detector (Figure 1-1), and are accessible when the detector has been detached from the detector base.




Figure 4-12: Wiring Terminals

4.2.3 Relays

The relays interface to the Fire Alarm Control Panel (FACP) to communicate fault and alarm states. Refer to Figure 4-12 above for the location of the relay terminals.

FAULT, PRE-ALARM and FIRE Relay Terminals

The FAULT relay is energized during normal operation while the PRE-ALARM and FIRE relays are only energized when the respective alarm thresholds are exceeded after the configured time delay. The operation of the relays are summarized in the following table.

Table 4-1: Fault and Fire Relay Operation

FAULT Relay		PRE-ALARM and FIRE Relay																					
Normal Operation (Energized)	Fault or un-powered state	Normal Operation (De-energized)	Pre-Alarm or Fire																				
<table border="1"> <tr> <td rowspan="3">FAULT</td> <td>NC</td> <td rowspan="3"> </td> </tr> <tr> <td>C</td> </tr> <tr> <td>NO</td> </tr> </table>	FAULT	NC		C	NO	<table border="1"> <tr> <td rowspan="3">FAULT</td> <td>NC</td> <td rowspan="3"> </td> </tr> <tr> <td>C</td> </tr> <tr> <td>NO</td> </tr> </table>	FAULT	NC		C	NO	<table border="1"> <tr> <td rowspan="3">FIRE</td> <td>NC</td> <td rowspan="3"> </td> </tr> <tr> <td>C</td> </tr> <tr> <td>NO</td> </tr> </table>	FIRE	NC		C	NO	<table border="1"> <tr> <td rowspan="3">FIRE</td> <td>NC</td> <td rowspan="3"> </td> </tr> <tr> <td>C</td> </tr> <tr> <td>NO</td> </tr> </table>	FIRE	NC		C	NO
FAULT		NC																					
		C																					
	NO																						
FAULT	NC																						
	C																						
	NO																						
FIRE	NC																						
	C																						
	NO																						
FIRE	NC																						
	C																						
	NO																						

4.2.4 Monitored General Purpose Input (GPI)

The GPI is a programmable input which can be configured to initiate a number of different actions, including, by default, a Remote Reset function. Refer to Section 7.3 on page 34 for GPI configuration options.

With monitored GPI, the detector monitors the GPI for open or short circuit faults when the GPI function is set to any value.

When the GPI function parameter is set to PSU monitoring, the detector indicates an external equipment fault condition by monitoring the line impedance. A 47K End of Line (EOL) resistor is supplied with the product and must be assembled in parallel with the device to be monitored.

The EOL resistor provides a known termination to the external equipment, this allows the detector to identify open or short circuits.

4.2.5 Typical Wiring for Monitored GPI for PSU Monitoring

The diagram below shows the correct way to configure power supply monitoring. It also shows where an End of Line (EOL) resistor is correctly installed.




Figure 4-13: Power Supply Connection Diagram

4.2.6 Typical Wiring to a Fire Alarm Control Panel (FACP)

The diagram below shows the correct way to wire VESDA detectors to a conventional fire alarm control panel (FACP). It also shows where an End Of Line (EOL) resistor is correctly installed.




Figure 4-14: Typical wiring to a fire panel with EOL

4.2.7 Wiring to an Addressable Loop Module

This wiring example is for wiring VESDA detectors to a typical Input/Output Loop module 3 inputs 1 output.

Note: These are example drawings. Refer to the appropriate product manual for the exact wiring details of the third party equipment.




Figure 4-15: Input/Output Loop Module with EOL

4.3 Specify Backup Battery for Power Supply

In the event of a mains power supply disruption, the VLQ detector runs on a backup battery connected to the external power supply. The size of the battery is determined by:

- local codes and standards
- the total power required by the system
- back up time required
- allowance for reduction in capacity with age
- expected temperature variations

Note: It is recommended that batteries connected to the external power supply be inspected and changed as per manufacturer's specifications or as per local codes and standards.

To facilitate the calculation of the backup battery size, a Battery Calculation Sheet is included below.

Table 4-2: Calculating the size of backup battery

Equipment	Normal loads @ 24 V DC			Full alarm load @ 24 V DC		
	Load mA	Qty	Total	Load mA	Qty	Total
Detector	170			190		
Other 24V Loads		Total mA			Total mA	
			X			X
	Standby Hours			Alarm Hours		
			=			
	Standby Capacity			Alarm Capacity		
				Total Capacity = Standby + Alarm		
				Divided by 1000 for Standby Capacity		
				Multiply by battery factor X1.25		

4.4 Installation Checklist

Site Name	
Address	
Detector Serial Number(s) and Date of Manufacture	
Name of Installer	
Signature	
Date	

Perform the following checks listed below to ensure that all the necessary items are completed before handing over to a commissioning engineer.

Installation Checks	Yes	No
Is the detector securely locked onto the mounting surface?		
Are the sampling pipes firmly connected to the air inlet ports? Ensure that the pipes are <u>NOT</u> glued into the detector.		
Is power supply installed in accordance with local electrical codes and the power wires been connected to the correct terminals inside the detector?		
If required, has the GPI end of line resistor (EOL) been connected?		
Have the alarm and fault signaling wires been terminated to the correct terminals on the detector?		
Is the air sampling pipework installed and checked as per the site plans?		

4.5 Powering Up

After installing the detector it is necessary to power up the system. The power up sequence lasts approximately two minutes.

The VESDA VLQ detector does not have a power switch, i.e it is hard wired to a 24 VDC supply and it is assumed that the power supply has been installed as per manufacturers instructions in accordance with local electrical codes.

If the system fails to power up, check all power wires are secured to their terminals and that the polarity is correct.

On power up:

- The Power LED illuminates and the detector runs a series of self-diagnostic and lamp tests.
- If there is a fault, the Fault LED illuminates. To identify the fault, check the fault code on the display panel or within the Xtralis QSC software.
- The aspirator starts.

It is normal for the detector to display faults immediately after the first power up. Reset the detector using the Xtralis QSC software or the reset button on the detector. This will unlatch the relays and turn off the Fault LED. Any remaining faults will cause the Fault LED to illuminate again. Proceed with the preliminary system check.

4.6 Preliminary System Check

A preliminary system check is required after installing the VESDA VLQ detector, before it is commissioned for use. The check can be conducted by using buttons on the detector or by connecting to the detector using the Xtralis QSC software. The preliminary systems check includes:

- Normalizing the air flow. Activate the normalization process using the N button on the detector or by using Xtralis QSC.
- Conducting a basic smoke test.
- Check interface to FACP, i.e. verify alarm and fault conditions.

This page is intentionally left blank.

5 Configuration

The VESDA VLQ detector is configured using the Xtralis QSC software or onboard DIP switches.

5.1 Logging on using the Display Panel

Prior to configuring or operating the detector using the display panel controls, it is necessary to log in to the detector.

Login Sequence



To log out of the detector, use the same sequence. Once logged in, the detector shows "Ln" on the display.

Note: When detector is logged-on from the front panel, it is not possible to log-on from Xtralis QSC, and vice-versa.

5.2 Setting the time using the Display Panel

It is possible to set the time by the detector control panel or the Xtralis QSC software.

Setting the time using Xtralis QSC

1. Log onto the detector.
2. Press the Set Time button.
3. The current Hour, Minute, Second, Year, Month and Day settings are displayed in a pop-up window. Edit as required then confirm the changes.

Setting the time using the Control Panel

1. Log on to the detector. Refer to Section 5.1 for further information.
2. Press and hold the Reset and Normalize buttons simultaneously for 5 seconds.
3. Set the hour by pressing the Test button to set the first digit, and the Disable button to set the second digit. Press the Reset button when the correct value is on screen to advance.
4. Set the minute by pressing the Test button to set the first digit, and the Disable button to set the second digit. Press the Reset button when the correct value is on screen to advance.
5. Set the second by pressing the Test button to set the first digit, and the Disable button to set the second digit. Press the Reset button when the correct value is on screen to advance.
6. Set the year by pressing the Test button to set the first digit, and the Disable button to set the second digit. Press the Reset button when the correct value is on screen to advance.
7. Set the month by pressing the Test button to set the first digit, and the Disable button to set the second digit. Press the Reset button when the correct value is on screen to advance.
8. Set the day by pressing the Test button to set the first digit, and the Disable button to set the second digit. Press the Reset button.

5.3 DIP Switch Configuration

The VESDA VLQ provides a range of configuration options using an on-board DIP Switch bank.




Figure 5-1: DIP Switch Location

Table 5-1: DIP Switch Configuration

Switch Position	Purpose	Configuration			Options	Default Switch Settings
		SW1	SW2	SW3		
1,2,3	Set Fire Alarm Smoke Threshold (Pre-alarm set to 50% of Fire Alarm automatically)	OFF	OFF	OFF	0.15%/m (0.046%/ft)	0.3%/m (0.091%/ft)
		ON	OFF	OFF	0.3%/m (0.091%/ft)	
		OFF	ON	OFF	0.6%/m (0.18%/ft)	
		ON	ON	OFF	0.8%/m (0.28%/ft)	
		OFF	OFF	ON	1.0%/m (0.30%/ft)	
		ON	OFF	ON	1.5%/m (0.46%/ft)	
		OFF	ON	ON	2.0%/m (0.61%/ft)	
		ON	ON	ON	3.0%/m (0.91%/ft)	
4	Set Fire Alarm Delays	OFF			No Delay	OFF (No Delay)
		ON			30s Delay	
5	Set Flow Delays	OFF			No Delay	OFF (No Delay)
		ON			30s Delay	
6	Set Fire Alarm latching	OFF			Fire Alarms not latched	ON (Latched)
		ON			Fire Alarms latched	
7	Set Fault latching	OFF			Faults not latched	ON (Latched)
		ON			Faults latched	
8	Set Flow Fault Limits	OFF			+/-20%	ON (+/-50%)
		ON			+/-50%	

6 Commissioning

The VESDA VLQ has been designed to simplify the commissioning process. The AutoLearn function allows the unit to assess its environment and setup appropriate alarm thresholds.

The detector is monitored during commissioning using Xtralis QSC.

Once the VESDA VLQ detector has been commissioned, it will report alarms and faults according to the parameters defined during installation.

Note: Detectors should be commissioned with a smoke test.

Prior to commissioning the detector:

1. Check that the pipe network is clean and correctly fitted with all joints correctly glued (except where the pipe enters the detector, which must not be glued).
2. Check that the power is connected and on. Let the detector run for around 5 minutes. Ignore the faults during this time. Reset the detector after 5 minutes of operation.
3. Normalize the airflow. This takes approximately 5 minutes.
4. Reset the detector after normalization. It should now be running without faults.

It is important that the protected environment is representative of normal operating conditions during the AutoLearn process.

For code-specific information, see Codes and Standards Information for Air Sampling Smoke Detection on page iii.

6.1 AutoLearn Smoke

AutoLearn Smoke is initiated by using controls on the front panel or from within Xtralis QSC.

During the AutoLearn Smoke process, the detector determines the average smoke and peak smoke obscuration levels and sets suitable alarm thresholds for the operating environment. This process will minimize nuisance alarms due to normal environmental background variations.

During the learning cycle, if an alarm condition occurs, AutoLearn will not complete its cycle. In this situation the user must restart the AutoLearn process. If AutoLearn is halted, the alarm thresholds will be left at the previous settings.

Conditions experienced during learning are assumed to be representative of normal operating conditions.

The AutoLearn Smoke learning times range from 15 minutes to 2 hours.

Note: AutoLearn Smoke thresholds are volatile, therefore if thresholds are set using AutoLearn smoke then it must be run each time the detector is powered up.

6.2 Commissioning Smoke Test

It is recommended that a smoke test be carried out to verify the integrity of the pipe network, to demonstrate that the system is working and to measure the transport time to the detector.

This test involves introducing a smoke sample at the furthest sampling hole and then measuring the time taken for the smoke to travel to the detector. Results are logged and compared to subsequent tests to note variations of the system.

This page is intentionally left blank.

7 Xtralis QSC Software

Xtralis QSC is used for configuration and commissioning of the VESDA VLQ detector.

Buttons are green and change to pink when active, and only when logged on to VESDA VLQ are all the buttons are visible.

7.1 Installation

1. Install the STM virtual COM Driver. Use the 32 bit (VCP_V1.x.x_Setup.exe) or 64 bit (VCP_V1.x.x_Setup_x64.exe) installer as appropriate for your Windows operating system.
2. Extract the Xtralis QSC executable (QSC.exe) to a folder on your PC's hard drive but do not run it before powering up the detector.
3. Connect a USB cable between the detector and the PC.
4. Apply power to the detector.
5. Launch Xtralis QSC. Xtralis QSC will report "Unable to open communication".
6. Select Connection Parameters, and select the available COM port then OK.
7. Once connected, the detector time will be displayed at the bottom of the window and "Self_test" or "Running" will be displayed in the status bar.

7.2 Functions

Table 7-1 below details Xtralis QSC commands (functions):

Table 7-1: Xtralis QSC Commands

Button / Function	Action
Logon / off	Default with Logon written. When pressed turns to Pink and prompts user with another screen to login to the VESDA VLQ unit. Press OK when Login screen pops up. Successful logon makes other buttons visible where login is required to perform such functions.
Reset	Resets alarms and faults when pressed and momentarily changes to Pink and back to Green when reset is completed.
Silence	Silences the buzzer and changes to Pink.
Connection Parameters	Allows to choose the communication port, change to appropriate virtual com port.
Reset Filter Use Percentage	VESDA VLQ stores smoke hours to determine filter usage and raises a trouble to replace the filter when certain smoke hours limit is reached. This button allows to reset the smoke hours when an expired filter is replaced with a new filter. Filter must be removed from the unit to use this function.
Lamp Test	Allows to perform LED, Buzzer and display test once.
Alarm and Relay Test	Allows to perform fire and fault relay test, prompts the user with another screen to test fire and fault relays. Alarm test simulates the smoke value to generate an Alarm condition.
AutoLearn Smoke	Allows to start AutoLearn smoke feature. AutoLearn uses background conditions to set appropriate thresholds.
Normalize Airflow	This button allows air flow normalization if the detector airflow is within the acceptable range. Normalization takes approximately 5 minutes.
Disable On	Allows disabling of the detector, when disabled detector stops reporting alarms on relays.
Standby On	Allows setting the detector to standby. The detector shuts down the aspirator and stops airflow and smoke detection.

Table 7-1: Xtralis QSC Commands (continued...)

Button / Function	Action
Set Time	Allows setting of the detector time, chose set to PC time for this version
Get Event Log	Allows to log up to last 1000 events and stores in a CSV file (do not change any timing on the right side up down button)
Get Smoke	Allows logging of smoke at between 1 and 60 second intervals and stores in a CSV file, this is useful to determine minimum and maximum thresholds settings during the fire tests if required. It is recommended that the smoke interval is set to 10 seconds or greater. This is a live smoke data capture so Xtralis QSC must be running during this function.

7.3 Configuration

Table 7-2 below details VLQ configuration items available in the Xtralis QSC software, under Device Configuration.

Table 7-2: Configuration Items

Configuration Item	Description	Parameters / Range
Configure via Xtralis QSC	Allow configuration of the detector from Xtralis QSC.	Enable/Disable
Unit	Set the units of smoke	Metric/Imperial
Fire Alarm Threshold	Set the threshold of Fire alarm	0.15%obs/m - 3%obs/m (0.046%/ft - 0.915%/ft)
Pre-Alarm Threshold	Set the threshold of Pre-alarm	0.1%obs/m - 1.5%obs/m (0.03%/ft - 0.457%/ft)
Alarm Delay	Configure delay of fire alarm	0, 30, 45 or 60 seconds
Alarm Latching	Allows to latch the fire relay	Enable/Disable
Fault Latching	Allows to latch the fault relay	Enable/Disable
Flow Fault Limit	Set the limit of flow fault	+/-20%, +/-50%
Fault Delay	Configure delay of fault	0, 30, 45 or 60 seconds
GPI Configuration	Configure the GPI action	<ul style="list-style-type: none"> • Reset • External Device (PSU) Monitoring • Reset+Disable • Standby
Buzzer	Enable or disable buzzer	Enable/Disable

7.4 Device Information

Table 7-3 below details information for the VLQ available in the Xtralis QSC software, under Device Information.

Table 7-3: Device Information

Item	Description
Model	Displays model number
Serial Number	Displays serial number
Hardware Version	Displays hardware version
Software Version	Displays software version
Manufacturing Date	Displays manufacturing date
Temperature	Displays current temperature
Smoke Value	Displays current smoke value
Flow Value	Displays current raw flow value
Filter Used	Display filter use percentage value

This page is intentionally left blank.

8 Maintenance

To maintain the VESDA VLQ detector at its peak performance level, the recommended maintenance schedule shown in Table 8-1 below should be followed.

Table 8-1: Recommended maintenance schedule for the VESDA VLQ detector

Maintenance Check	Quarterly	Six-monthly	Annual	Biennial
Power Supply and Battery	✓			
Check Pipes		✓		
Pipe Integrity Smoke Test			✓	
Check Pipe Flow			✓	
Clean Sampling Points			✓	
Flush Pipe Network			✓	
Replace Filter				✓

8.1 Replacing the Filter

The detector reports a fault condition on the front panel and in the event log to indicate that the filter requires replacement after the recommended period of time has elapsed, or filter use percentage limit reached, whichever occurs first.

After removing the old filter and prior to inserting the new one, it is necessary to reset the filter used percentage value. This can be done using the detector controls or from within Xtralis QSC.

Requirements

Philips head screwdriver

Filter Removal Procedure

1. Rotate cover 45° counter-clockwise and remove by lifting outwards (Figure 8-1).




Figure 8-1: Remove the Detector Cover

2. Release the filter:
 - **Where the filter is secured with a retaining bracket:** Remove screws (C) with a Philips head screwdriver and lift out the filter retaining bracket (D) (Figure 8-2).




Figure 8-2: Remove filter retaining bracket

- **Where the filter is secured with retaining clips:** Whilst holding the filter housing (B), loosen the screws C and D with a Philips head screwdriver. turn the clips (E and F) outwards, away from the magnets beneath them (Figure 8-3).




Figure 8-3: Loosen filter retaining screws

2. Lift the filter (G) out of the detector (Figure 8-4).




Figure 8-4: Remove Filter

Filter Insertion Procedure

1. With the filter removed from the detector, pressing Test and Disable button simultaneously displays filter use percentage value. When a new filter is used reset the filter use percentage value. To do this, press the Reset button on the front panel once, or use the Xtralis QSC software.
2. Tilt the new filter and align to the insertion guides (Figure 8-5) and lower filter into place.




Figure 8-5: Filter insertion

3. Reposition the retaining bracket, or for units with retaining clips, realign the clips with the magnets (Figure 8-3, C and D).
4. Tighten the retaining screws using a Philips head screwdriver.

This page is intentionally left blank.

9 Troubleshooting

9.1 Fault Codes

Fault codes can be viewed on the LED display or by using the Xtralis QSC software.

- Faults 01 through to 18 are hardware faults which require that the detector be replaced.
- Faults 41 through to 50 are generally rectifiable with minimal user interaction.
- To correct some faults, you may be prompted to log on to the detector. The login procedure is described in Section 5.1 on page 29.

Table 9-1: Fault Codes

Fault Code	Fault Type	Description	Possible Resolution
01	Detector Hardware	Self-test failed	Contact your authorized service representative.
03		EEPROM fault	
04		Calibration data EEPROM fault	
05		Configuration fault	
06		+12V fan power supply fault / main board module fault	
07		+5V power supply fault	
08		3.3V power supply fault / main board version fault	
09		Laser control circuit fault	
10		Smoke signal receive and amplification circuit fault	
11		Fans fault	
12		Flow circuit fault	
13		Ambient temperature circuit fault	
14		Fault relay control circuit fault	
15		Alarm relay control circuit fault	
16		RTC fault	
17		Chamber BG too high	
18		Chamber BG too low	
41		24V input power supply fault	
42	Airflow Normalization Failed	The detector has been unable to establish a reference level for normal airflow.	Check the sample holes, pipe and connection to the unit for obstruction and integrity. Make corrections as required, restart the unit, wait 10 minutes then normalize again.

Table 9-1: Fault Codes (continued...)

Fault Code	Fault Type	Description	Possible Resolution
43	Autolearn Smoke Failed	The detector has been unable to establish suitable alarm thresholds during Autolearn Smoke.	Re-activate when area is smoke-free, or set suitable Pre-Alarm and Fire thresholds manually using the onboard DIP switches or the Xtralis QSC software. Refer to Section 5.3 on page 30 for further information
44	Filter Absent	Filter not fitted or fitted incorrectly	Check filter is fitted correctly or insert new filter. Refer to Section 8.1 on page 37 for further information.
45	Filter Replace	Filter life expired	Replace filter and reset filter use percentage value. Refer to Section 8.1 on page 37 for further information.
46	High Airflow	Airflow through one or both sample pipes has exceeded the acceptable high flow limit.	<ul style="list-style-type: none"> • Check sample pipes for damage, breaks. • Examine environment for changes that may affect airflow. If a cause cannot be found, normalize the detector.
47	Low Airflow	Airflow through one or both sample pipes has exceeded the acceptable low flow limit.	<ul style="list-style-type: none"> • Check sampling holes and pipe for obstruction or partial blockage. • Examine environment for changes that may affect airflow. If a cause cannot be found, normalize the detector.
48	GPI	The monitored General Purpose Input line is open or short circuit.	The End Of Line resistor provides a known termination to the external equipment. Check that the 47K EOL resistor is fitted to the GPI terminals on the back of the unit. Examine monitored device (if fitted). Refer to Section 4.2.5 on page 23 for further information.

Table 9-1: Fault Codes (continued...)

Fault Code	Fault Type	Description	Possible Resolution
49	External Device on GPI	External device failure	Check that the EOL resistor is fitted. Examine monitored device (if fitted). Refer to Section 4.2.5 on page 23 for further information.
50	Display Panel	Display panel button stuck	Attempt to release button, check that the detector housing and front panel are correctly fitted and aligned.

This page is intentionally left blank.



Singapore +65 6757 7045

Indonesia +62 21 8778 2069